

# TECHNICAL INFORMATION

KLEEN  
PURGATIS

## STAINLESS STEEL CLEAN AND CARE LIQUID

### PRESTAN EDELSTAHLPFLEGER



Item Number 203.778 12 x 0.5L Bottle



- maintains and protects all **stainless steel surfaces**
- **maintains, polishes** and **protects, all-in-1**
- **dirt** and water repellent
- **prevents** rapid re-soiling, if **regularly** used
- creates a **shiny** protective film
- **avoids** visible fingerprints
- **suitable** for Chromium, Aluminum and anodized surfaces, Nickel and brass

#### RANGE OF APPLICATIONS:

Prestan Stainless Steel Cleaner cleans, maintains and protects all stainless steel surfaces as well as Chromium, Aluminum and anodised surfaces, Nickel and Brass.

#### INSTRUCTIONS FOR USE AND DOSAGE:

Initial care for stainless steel and other Materials

Remove coarse dirt from the surfaces before applying Prestan Stainless Steel Cleaner.

We recommend to clean surfaces with, for example Kraftreiniger Power Cleaner A, before using Prestan Stainless Steel Cleaner.

Then, wipe the surface with water.

Apply Prestan Stainless Steel Cleaner to a clean, dry and fluff-free cloth. Wipe and distribute the product evenly over the surface. Absorb residue Cleaner liquid, if any. Do not need to polish again.

For daily maintenance cleaning, only use on soiled area of the metal surfaces.

Not liable for surface damages resulted from improper use of the Cleaner liquid.

#### TECHNICAL DATA:

Appearance : ..... clear, colorless liquid

Smell : ..... after solvent

Viscosity : ..... low viscosity

Density : ..... 790 g/L

#### INGREDIENTS:

Over 30% : ..... Aliphatic hydrocarbons

Shelf life : ..... Minimum 1 year, stored in original container

#### IDENTIFICATION:



Danger



Contains Naphtha, low-boiling, modified

**Hazard Warnings:** H304: May be fatal if swallowed and enters airways. H315: Causes skin irritation. H319: Causes serious eye irritation.

#### Safety Information:

P101: If medical advice is needed, have product container or label at hand. P260: Do not breath vapor. P280: Wear gloves. P301 + 310: IF SWALLOWED: Immediately give call to the POISON CONTROL CENTRE or medical doctor. P331: DO NOT Induce vomiting. P305+351+338: IN CASE OF CONTACT WITH EYES: Rinse immediately with plenty of water and seek medical advice. Remove contact lenses, if present and easy to do. Continue rinsing. P302+352: IN THE CASE OF CONTACT WITH SKIN: Wash with plenty of water and soap.

#### TRANSPORT:

This product does not count as hazardous material for transport regulations (ADR).

 佳澤科技有限公司  
Delta Pyramax Co., Ltd.

#### HONG KONG

3/F, Unit A, Kader Building,  
22 Kai Cheung Road, Kowloon Bay  
Phone +852 2511 2118  
Fax +852 2507 5078  
sales@dpx.hk

[www.deltapyramax.com](http://www.deltapyramax.com)  
[www.kleen-purgatis.de](http://www.kleen-purgatis.de)